

REPLACEMENT PARTS LIST

Key	Qty	Description
1	1	KIT, TOP LID
2	1	TEMPERATURE GAUGE
3	1	BEZEL, F/ TEMPERATURE GAUGE
4	1	KIT, LOGO PLATE F/ LID
5	1	KIT, HANDLE, F/ LID
6	1	KIT, TOP LID HINGE PINS (SET OF 2)
7	1	KIT, REAR PANEL, TOP LID
8	1	FIREBOWL
9	1	KIT, HEAT SHIELD, F/ FIREBOWL
10	1	KIT, GREASE TRAY SUPPORT
11	1	UPPER REFLECTOR
12	1	VAPORIZER CONE
13	1	KIT, ELEMENT
14	1	POWER CONTROLLER
15	1	LED LIGHT RING
16	1	KIT, CONTROL PANEL
17	1	KIT, BEZEL F/ CONTROL KNOB
18	1	COVER, F/ CONTROLLER
19	1	KIT, BOTTOM SKIRT, CONTROL PANEL
20	1	CONTROL KNOB
21	1	WARMING RACK
22	1	GREASE TRAY
23	1	COOKING GRATE
24	1	EMITTER, F/ COOKING GRATE
25	1	LEFT SIDE SHELF, FIXED
26	2	KIT, FOLDING SHELF
27	1	KIT, FRONT BOTTOM SKIRT, FIXED LEFT SHELF
28	1	KIT, REAR BOTTOM SKIRT, FIXED LEFT SHELF
29	1	KIT, BOTTOM SKIRT, FOLDING LEFT SHELF
NOT Pictured		
...	1	PRODUCT GUIDE, EUROPE
...	1	HARDWARE PACK
...	1	GRATE CLEANING TOOL

Key	Qty	Description
30	2	LIFT HANDLE, SIDE SHELF
31	1	RIGHT SIDE SHELF, FIXED
32	1	KIT, FRONT BOTTOM SKIRT, FIXED RIGHT SHELF
33	1	KIT, REAR BOTTOM SKIRT, FIXED RIGHT SHELF
34	1	KIT, BOTTOM SKIRT, FOLDING RIGHT SHELF
35	1	LEG ASSY, TOP LEFT
36	1	LEG ASSY, TOP RIGHT
37	4	LEG CAP
38	1	LEG SUPPORT WIRE, STRAIGHT
39	1	LEFT LEG ASSEMBLY, FRONT
40	1	LEFT LEG ASSEMBLY, REAR
41	1	RIGHT LEG ASSEMBLY, FRONT
42	1	RIGHT LEG ASSEMBLY, REAR
43	2	CASTER, LOCKING
44	2	CASTER, NON-LOCKING
45	1	FRONT PANEL
46	1	LEFT CAP, FRONT PANEL
47	1	RIGHT CAP, FRONT PANEL
48	1	LEFT PANEL, F/ CART
49	1	RIGHT PANEL, F/ CART
50	1	LEFT CAP, SIDE PANEL
51	1	RIGHT CAP, SIDE PANEL
52	1	CART SUPPORT, CURVED
53	1	BOTTOM SHELF

NOTE: Some grill parts shown in the assembly steps may differ slightly in appearance from those on your particular grill model. However, the method of assembly remains the same.

REPLACEMENT PARTS DIAGRAM

